

INSTALLATION INSTRUCTIONS

Read installation instructions first before installing. Check parts to ensure that no damage has occurred during transit and that no parts are missing. Also check the diameter of the pipe and the range marked on the coupling to ensure you have the proper size.






Style IC501 Insulating Coupling

Step 1 • Check the coupling parts to insure that no damage has occurred during transit and that no parts are missing.


Step 2 • Clean each pipe end for a distance of 2" greater than length of the insulating boot.

Step 3 • Check area where gaskets will seat to make sure there are no dents, projections, gouges, etc., that will interfere with the gasket seal. Welds must be ground flush.

Step 4 • Place a reference mark on the pipe an equal distance from each pipe end for centering coupling over the pipe ends. There should be a minimum of 2" inches of pipe insertion per coupling end.



Step 10 • Center ring should be positioned such that the space between the OD of the pipe and the ID of the center ring is even all around the pipe. Slide gaskets into position with the beveled edge engaging the flared end of the center ring.



Installation Instructions continued on back


Note: Flexible Couplings do not provide protection against possible pullout of pipe ends in unrestrained conditions.

Document #20-9-501-0014 02/07/2022

Style IC501 (continued from front)

Step 12 • Check coupling for proper positioning over pipe ends using reference marks. (See Step 4)

Step 13 • Insert bolts into end ring and tighten. Bolt tightening should be done evenly, alternating to diametrically opposite positions at approximately 20 ft-lbs increments to bring bolts to recommended tightness



Nom. Pipe Diameter	Torque
2" - 12"	40-50 ft-lbs.
14" and above	60-70 ft-lbs.

Wait 10 minutes and retighten to account for settling of the gasket.



Step 14 • Confirm proper installation by pressurizing the line and checking for leaks.

PRECAUTIONS

1. Check diameter of pipe to make sure you are using the correct size coupling; also check gasket to make sure it is the size you think it is.
2. Clean pipe to remove dirt and corrosion from pipe surface. Lubrication and additional cleaning should be provided by brushing both the gasket and plain pipe end with soapy water or approved pipe lubricant per ANSI/AWWA C111/A21.11.
3. Make sure no foreign materials lodge between gasket and pipe.
4. Avoid loose fitting wrenches, or wrenches too short to achieve proper torque.
5. Keep threads free of foreign material to allow proper tightening.
6. Take extra care to follow proper bolt tightening procedures and torque recommendations. Bolts are often not tightened enough when a torque wrench is not used.
7. Pressure test for leaks before backfilling.
8. Backfill and compact carefully around pipe and fittings.
9. When reinstalling parts with stainless steel hardware, there may be a loss in pressure holding ability due to worn or damaged threads during the original installation.

COMMON INSTALLATION PROBLEMS

1. Bolts are not tightened to the proper torque.
2. Rocks or debris between pipe and gasket.
3. Dirt on threads of bolts or nuts.
4. Pipe not inserted into the coupling far enough.
5. Center ring not centered evenly around pipe.
6. Too much pipe deflection.
7. Putting on wrong gasket on insulating boot.